NUMC Room 237 & 239

AV Instructions Using a Guest attached/HDMI Laptop or MAC

1) Attach your Laptop/MAC with the HDMI cable from the wall plate to your Laptop/MAC. Boot up your Laptop/MAC.



2) Pick up the remote and turn the on by pressing the top left RED POWER button.



3) Using the Remote Circular device to choose Up or Down, or Left or Right, whatever direction you need to go to get to the top left corner of the TV where there is an icon called Connected Devices. It is two down to the right of the Account. Once you select Connected Devices, a box menu shows the currently HDMIs that are being used by the TV. Look below at the picture showing the Connected Devices. You want to move down the list to **select HDMI3** using the remote and you will most likely have to answer a question using the remote to verify you want to use HDMI3.



Dallas Camera Club- There should be no need
to use the Dell Computer located behind
the Samsung TVs and connected to HDMI 4.

3) Using the Remote Circular device to choose Up or Down, or Left or Right, whatever direction you need to go to get to the top left corner of the TV where there is an icon called Connected Devices. It is two down to the right of the Account Icon. Once you select Connected Devices, a box menu shows the current HDMIs that are being used by the TV. Look below at the picture showing the Connected Devices. You want to move down the list to **select HDMI4** using the remote and you will most likely have to answer a question using the remote to verify you want to use HDMI4.





Dallas Camera Club- There should be no need
to use the Dell Computer located behind
the Samsung TVs and connected to HDMI 4.

4) Press the keyboard' space bar to get the login prompt for the PIN = 75230.



5) The mounted PC has a USB available for a flash drive just above the power buton, look at previously picture of the Dell that is attached to the TV.

6) The OWL bar and OWL are already configured to work with Zoom and Teams.

Dallas Camera Club- There should be no need
to use the Owl video conferencing system

Dallas Camera Club
Addendum

Error Message-
Failed HDMI Connection



Samsung TV- HDMI Ports



Samsung 100” TV- Room 237- Settings

- All Settings
  - Picture
    - Expert Settings
      - Brightness - 25
      - Contrast- 25
      - Sharpness- 10
      - Color- 25
      - Tint (G/R)- R5
      - Auto HDR Remastering- Off
      - HDR Tone Mapping- Static
      - Contrast Enhancer- Off
      - Shadow Detail- 0
      - Gamma- 2.2
      - Local Dimming- Low
      - Film Mode- Off
      - Color Space Settings- Custom
        - Red- 48
        - Green- 50
        - Blue- 50
      - Color Boost Pro- Off
      - Color Tone- Warm 1
      - White Balance- - No Change (default)
      - Picture Clarity- Off
      - Blue Light Reduction- Of
      - Picture Size Setting- 16:9 (Standard)
    - Picture Mode- Graphic

Samsung 100” TV- Room 239- Settings

- All Settings
  - Picture
    - Expert Settings
      - Brightness - 18
      - Contrast- 25
      - Sharpness- 10
      - Color- 25
      - Tint (G/R)- R5
      - Auto HDR Remastering- Off
      - HDR Tone Mapping- Static
      - Contrast Enhancer- Off
      - Shadow Detail- 0
      - Gamma- 2.2
      - Local Dimming- Low
      - Film Mode- Off
      - Color Space Settings- Custom
        - Red- 48
        - Green- 50
        - Blue- 50
      - Color Boost Pro- Off
      - Color Tone- Warm 1
      - White Balance- - No Change (default)
      - Picture Clarity- Off
      - Blue Light Reduction- Off
      - Picture Size Setting- 16:9 (Standard)
    - Picture Mode- Graphic